

Thank you for purchasing our product.

**Please read these instructions before use. The manufacturer is not liable for any damage caused by improper use.**

### **Switching on/off the iTag**

Gently hold down the side button for 3–5 seconds.

- a. Short sound = iTag is switching on
- b. Two beeps = iTag is switching off

### **Adding iTag to the application Find my iPhone**

1. Switch on iTag by holding down the side button (it will make a short sound)
2. Open the application Find my iPhone
3. From the lower menu select Items and click on +
4. Select **Add a different item**
5. Upon finding it, iTag will appear on the display – click on Connect
6. Name the item and click on Continue
7. Select Emoticon and click on Continue
8. Click on I agree
9. Click on Complete

If iTag cannot be found, switch it on by holding down the side button (it will make a short sound) and try to add it again following the steps above.

### **Changing the battery**

**If the iTag cannot be switched on by holding down the side button, change the battery (CR2032).**

1. Press down the rear cover and while pressing carefully turn the rear cover in a counterclockwise direction
2. The detached rear cover can now be easily removed
3. Carefully remove the battery so as not to damage the battery's clips
4. Insert a new battery
5. Place the rear cover into the marked holes, clip it back, press down and carefully turn the rear cover in a clockwise direction

### **Important warnings, recommendations and FAQs**

1. The product contains a battery. Do not expose it to flames or extreme temperatures due to risk of explosion.
2. Keep the product out of reach of children. It may contain small parts posing risk of inhalation.
3. Do not use the product if it is damaged in any way or if the battery is incorrectly inserted, or damaged.
4. Do not use the product in close proximity to explosives and chemicals.
5. Protect the product from falls or impacts; do not expose it to extreme temperatures or direct sunlight. These conditions may cause malfunctions, or they can cause irreparable damage. Keep the product at room temperature.
6. Prevent it from coming into contact with water. After the product comes into contact with water, dry it.

**Notes:** All images and descriptions of functions may differ to your version of the product and are used for illustrative purposes only.

### **Safe disposal of the product**



Do not dispose of the product in general waste as it may contain substances harmful to the environment.



### **Electronic waste**

Leave the product at a dedicated electronic waste collection facility where its recycling or safe disposal is ensured. Contact your local municipality for a list of waste collection sites, or you can leave the used product with the seller.

**Technical requirements for the telephone:** iOS 14.5+

**Frequency band:** 2402–2480 MHz

**Max. performance:** 1.06 dBm

### **Declaration of conformity**

ARMODD GmbH hereby declares that the ARMODD iTag device complies with Directive 2014/53/EU. The full version of the EU declaration of conformity is available at this website: [www.armodd.com](http://www.armodd.com)

**Technical support:** [info@armodd.com](mailto:info@armodd.com)

Manufacturer: ARMODD GmbH, Königstraße 80, 70173 Stuttgart, Germany